

Wiring Instructions for RGB Rope Light Controller:

1. Strip the four wires from the RGB Rope Connector. The brown wire from the RGB rope connector screws into the red outlet on the back of the controller.
2. The other three wires may connect into either of the other three outlets on the back of the controller.
3. The controller allows for 7 solid colors, color change and color wash.
4. Push the button on the controller to advance the program. Turn the knob on the controller to slow it down or speed it up during color wash or color change effects.

