

RGB ROPE LIGHT




Wiring Instructions for the RGB Rope Light Controller Cable to the Pavo Dial Controller.

When you remove the plastic covering of the Pavo Dial, you can get behind the controller and access the screw terminals.



Wiring the RGB Rope Controller Cable to the Pavo Dial's Screw terminal:

1. Connect the **BLUE** wire to the **V** terminal.
2. Connect the **BLACK** wire to the **B** terminal.
3. Connect the **RED** wire to the **G** terminal.
4. Connect the **GREEN** wire to the **R** terminal.



Behind the Pavo Dial Controller