

Reach TR Accessories



Now Reach TR is READY for TV, film and touring! These robust accessory holders give the super-bright fixtures the look and feel of professional production fixtures, and there's a full line of accessories to go along.

For Use with:

Philips Color Kinetics Color/iW/eW Reach TR Fixtures

Part Number	Description	✓
4700.TD	Reach TR Accessory Holder, Yoke and Data Enabler mount	
4700.TR	Reach TR Accessory Holder, Yoke	
4710.EC	Reach Egg Crate Louver	
4720.HH	Reach Half Hat	
4715.HH	Reach High Hat	
4725.BD	Reach 8-leaf Barn Door	
4730.GF	Reach Gel Frame	
4700.RK	Spare Reach Yoke Locking Knob	

Job Name	
Location	
Architect	
Designer	



Half Hat



High Hat



8-Leaf Barn Door

These Accessory Holders have two slots, to accept any combination of hats/barndoors, egg crates and gel frames. Lens changing is easy with quick-action lens toggles.

With a heavy-duty tubular steel yoke, real molded locking knob, and a flat base, this fixture is now truly road ready. A TV pin is provided as standard.

The 4700.TD has a mount behind the fixture for a data enabler, so each fixture gets AC power and a DMX daisy-chain.



In the interest of continuous product improvement, specifications are subject to change without notice