

Wall Switch 1.7 (9600 8 N 1)

Wall Switch Modes and Button Functions

To change Switch Mode - Hold button 1 (White Stars), button 2 (Advanced), button 3 (RGB Stars), button 4 (Mini Lights), button 5 (Stars with a Shooting Star), or button 6 (Epic 4 Stars) while powering up, the corresponding button will flash 10 times.

Button	Mode 1 - Controlling Stars	
	Short Press - < 1 Second	Long Press - > 1 Second
1	Stars on solid 100%	Stars on solid 100%
2	Stars off	Stars off
3	Tropical Winds - Fast Sparkle	Tropical Winds - Fast Sparkle
4	Night Sky - 3D Perspective	Night Sky - 3D Perspective
5	Sleep Mode - Will turn off Stars in 60 min. - Button LED will breathe	Sleep Mode - Will turn off Stars in 60 min. - Button LED will breathe
6	Rain Shower	Rain Shower
Button	Mode 2 - Controlling Epic Advanced	
	Short Press - < 1 Second	Long Press - > 1 Second
1	Solid color select	Reset solid color to color 1 - Warm White
2	RGB Dim - All RGB channels dim 4%	Pauses color cycle
3	Recall solid color preset A	Save solid color preset A
4	Recall solid color preset B	Save solid color preset B
5	Show select	Reset show to show 1 - Color Cycle
6	All LED Channels off	Sleep Mode - Will turn off LEDs in 60 min. - Button LED will breathe
Button	Mode 3 - Controlling RGB Stars	
	Short Press - < 1 Second	Long Press - > 1 Second
1	Kalidascope	Party Mode
2	Chroma Sweep	Iridescent White
3	Dim by 10%	Dim directly to 10%
4	Brighten by 10%	Brighten directly to 100%
5	Solid Color Sparkle Select	Go to color 1 sparkle (blue)
6	RGB Stars off	Sleep Mode - Will turn off LEDs in 60 min. - Button LED will breathe
Button	Mode 4 - Controlling Mini Lights	
	Short Press - < 1 Second	Long Press - > 1 Second
1	Sets Both Channels to 100%	Sets Both Channels to 100%
2	Sets Both Channels to 75%	Sets Both Channels to 75%
3	Sets Both Channels to 50%	Sets Both Channels to 50%
4	Sets Both Channels to 25%	Sets Both Channels to 25%
5	Sets Both Channels to 10%	Sets Both Channels to 10%
6	Turns Both channels off	Turns Both channels off
Button	Mode 5 - Controlling Stars and a Shooting Star	
	Short Press - < 1 Second	Long Press - > 1 Second
1	Night Sky - 3D Perspective	Night Sky - 3D Perspective
2	Rain Shower	Rain Shower
3	Party Mode	Party Mode
4	Stars on solid 100%	Stars on solid 25%
5	Shooting Star every 10 seconds	Shooting Star every Minute
6	Global Off	Sleep Mode - Will turn off Stars in 60 min. - Button LED will breathe